

iKeyp® BOLT

Quick Start Guide



In the Box

- 1 Wi-Fi activity LED
- 2 Battery level LED
- 3 Status indicator LED
- 4 Screw hole
- 5 Screw hole cover
- 6 Main compartment door
- 7 Easy open door assist
- 8 Recessed door handle
- 9 Humidity resistant seal
- 10 Battery compartment
- 11 Backup key access
- 12 Water resistant keypad



- 1x iKey Bolt PART #KYPT
- 1x Battery Cover PART #KYPT-02
- 2x Backup Keys PART #KYPT-03
- 3x Phillips Head Screws PART #KYPT-04
- 3x Wall Anchors PART #KYPT-05
- 3x Screw Hole Covers PART #KYPT-06
- 1x Quick Start Guide PART #KYPT-07
- 1x Registration Card PART #KYPT-08
- 1x Mounting Instructions PART #KYPT-09
- 1x Mounting Template PART #KYPT-10
- 1x Wall Anchor Instructions PART #KYPT-11

 Requires 4x AA Alkaline batteries.

Quick Start Instructions

! Carefully unpack the iKey Bolt from the retail packaging box.

1. Open the iKey by inserting one of the backup keys into the keyhole and turning it counter-clockwise (to the left) until the main compartment door gently pops open.
2. Identify all items in the box listed on the previous page. If any parts are missing or defective, please call Customer Support at **+1 (800) 485-8904** for replacement parts.
3. Insert four (4) new **AA Alkaline batteries** into the battery compartment (located on the inside left of the main compartment) by first opening and removing the battery cover. Ensuring correct polarity according to **Diagram A** (right), insert the batteries, then replace and securely close the battery cover.




DIAGRAM A

! **IMPORTANT**

- 1) **Do NOT** use or place rechargeable batteries in the iKey Bolt battery compartment.
- 2) **Do NOT** mix old and new batteries.
- 3) **Do NOT** mix alkaline and standard (carbon-zinc) batteries.

4. To ensure batteries have been installed correctly and are in working order, once the battery compartment cover has been closed, the “Battery” LED on the front of the safe will be solid **green** (the internal lock may also be heard turning).
5. Please **STOP** and **READ** below to determine if you want to use your iKey Bolt in *Connected Mode* or *Offline Mode*. You can always change back and forth at any time.



CONNECTED MODE

This mode is internet-enabled with support for smartphone app alerts, reminders, reporting and remote operation. **This is the recommended mode of operation.** If internet connectivity is lost or out of range, the safe will securely default to Offline Mode. Please see the next page for Connected Mode Setup instructions.



OFFLINE MODE

This mode is NOT internet-connected and uses the safe’s basic onboard visual and audio alarms and indicators. Please see reverse side for Offline Mode Usage instructions on how to use the safe while offline.

When using the iKey mobile app to setup your iKey Bolt, you will automatically register the product and activate the warranty. If you plan to use the iKey Bolt in *Offline Mode*, please register at [iKey.com/support](https://www.iKey.com/support) or call Customer Support at **+1 (800) 485-8904**.

 **WARNING Do NOT store any life saving medication in this safe at any time.**

Connected Mode Setup

Connected Mode is for individuals who want to use their smartphone to monitor and remotely operate their iKey Bolt, and to take advantage of additional features and custom settings.

✓ For a complete list of *Connected Mode* features please visit iKey.com/support

DOWNLOAD THE IKEY APP

Please download the iKey App on the App Store® for iPhone® or on Google Play from your Android™ device to use *Connected Mode*.



Apple, the Apple logo, iPhone, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc., registered in the U.S. and other countries. Android, Google Play and the Google Play logo are trademarks of Google Inc.

After the iKey App is installed, please follow the on-screen app instructions to complete the setup of your iKey Bolt. If you cannot download the app or have questions regarding the smartphone operating systems supported, please visit iKey.com/support



If internet connectivity is lost or out of range, the iKey will securely default to *Offline Mode*. It is therefore important to be familiar with using your iKey Bolt in *Offline Mode* even if you prefer to use *Connected Mode* normally. Please see the *Offline Mode Usage* section on page 6 to use the safe while offline.

Change User Access Code

If using the iKey Bolt in either *Connected* or *Offline Mode* you should change the factory default user access code to ensure it cannot be used to gain unauthorized access. Follow these steps at any time to set a new user access code:

! **IMPORTANT:** The default keypad sequence to open the safe door is **1-2-3-4-ENT**.

Enter the **current** user access code on the keypad to unlock the main compartment door. You may also use a Backup Key to unlock the door.

1. With the main door open, press and hold the “ENT” key until the iKey beeps.
2. Enter any 4-8 digit key length combination on the keypad then press the “ENT” key. The iKey will beep and the “Status” LED will flash **yellow three times** and then turn solid.
3. Re-enter the same combination again and then press “ENT” key to confirm the new user access code.

If the combination is accepted, the iKey will beep and the “Status” LED will flash solid **green three times**, otherwise the LED will flash **red three times**, and you must close the main door and then repeat steps 1 through 3.


Solo Technology Holdings, LLC

Purchase, NY 10577

United States of America

iKey.com

+1 (800) 485-8904



Offline Mode

Offline Mode is for users who prefer **NOT** to use a smartphone with their iKey Bolt or do **NOT** have Wi-Fi with internet access for connecting the iKey Bolt.

- ✓ For a complete list of *Offline Mode* features and a list of shortcuts for programming functions, please visit **iKey.com/support**

VISUAL AND AUDIBLE ALERTS

If you choose to use your iKey Bolt in *Offline Mode* instead of the recommended *Connected Mode*, visual and audible alerts from the iKey will continue to function but other *Connected Mode* features and alerts will **NOT** be available.

The factory **default settings** for the iKey Bolt are shown in the table below:

iKey Bolt Feature	Feature Description	Setting
User Access Code	Opens the main compartment door	1-2-3-4-ENT
Tamper Detection	Detects motion, shock vibration, and three-axis titling of the device	Off

Installation Options

There are several ways to use your iKey Bolt. The two most popular are 1) to mount it directly to a wall using the included hardware or 2) to simply use it freestanding on a dresser, counter or tabletop.

MOUNTING DIRECTLY TO A WALL

- 1) Read the included instructions titled “**Mounting Instructions**” carefully to determine the best mounting option.
- 2) Use the “**Mounting Template**” to mark the installation location.
- 3) Refer to the “**Wall Anchor Installations**” to complete the installation.

▶ For further information and online video tutorials on how to install and uninstall the iKey Bolt, please visit iKey.com/support

! **IMPORTANT:** To arm the iKey Bolt with Tamper Detection, please follow the instructions below to toggle the feature between “On” and “Off”.

TOGGLE TAMPER DETECTION MODE

With the main door open, **Press the “0” key for 5 seconds** until the iKey beeps. Tamper Detection Mode will toggle between “Off” (factory default) and “On” with each use of this sequence.

? **NEED ASSISTANCE?**

If you have any questions, please visit iKey.com/support or call Customer Support at **+1 (800) 485-8904**.